


Viiv TV user guide

Section: Recordings

This section of the guide shows you how to:


- A. Record a program (episode or show) p.2
- B. Accessing your recordings p.4
- C. Watch a recording p.6
- D. Delete, stop modify a recording p.7

Remote control functions




A. Record a program (episode or show)

1. Press the **Guide button** on your remote control
2. Use the **arrows on your remote control** of your remote control to navigate to the program you want to record
3. Press the **OK** button to select the program




4. Choose **Record**



5. Then choose between the following options:


- a) Record **this episode only**
- b) Record **all episodes**




6. You can then set up your recordings:

- **Episodes:** allows you to select "New only" or "New and reruns"
- **Extend:** allows you to extend your recording by 5, 10, 30, or 60 minutes (useful when recording sports games or special programming that may run longer than scheduled)

Use the **OK button on the remote control to change an option**
Use the **arrows on the remote control to navigate through the options**




7. Press **OK** to confirm. A **red dot** will appear next to the program to confirm the recording



B. Accessing your recordings

There are two ways to access the recordings menu:

1. Pressing the **DVR button** on the remote control
2. Choosing **DVR in the menu bar** on your screen




Once in the recordings menu, you will have access to two options:

A. Recorded

- Displays all content that has already been recorded
- Includes the **Shows and Movies** sections

B. Scheduled

- Displays all upcoming recordings
- Includes single episodes and recurring shows



C. View a recording

1. Press the **Recorded** option
2. Use the **arrows on the remote control** to **highlight a title**, then press the **OK** button on your remote control to **select it**



3. Press **Play**




D. Delete, stop or modify a recording


In **Recorded**:



- Select the show
- Press **Delete** to erase an episode
- Press **Delete All Recordings** to clear all episodes




- Press **Recording Options** to change the recording rules




In Scheduled:

1. Use the **arrows on the remote control** to **highlight a title**, then press the **OK** button on your remote control to **select** it




- Select **Cancel** to cancel this episode
- Select **Cancel Series Recording** to cancel the series



Select **Extend** to add time to the recording (5, 10, 30, or 60 minutes)

- Press **Recording Options** to change the recording rules



Tips and Tricks

- **If a show is not recording:** check whether the “New Only” option is enabled. The show may be considered a rerun.
- **Extend the recording:** when recording live programs (news, sports, special events).
- **Keep an eye on the available recordings space** in the upper right corner.



- **To free up recording space:** Delete old recordings to free up space.