

How to free up recording space

When you delete a recording, it is kept for 72 hours in the Deleted section, which takes up space in your recording hours block. If your recording space is approaching its limit and you want to free up space quickly, simply **delete permanently** the programs you have already deleted.

Here are the steps to permanently delete recordings


1. Access your recordings :

- Press the **DVR** button on the remote control.




OR

- Press the TiVo button on the remote control and select the **DVR** section on the screen.



2. Access deleted programs:


- Access to the **Deleted** tab.



3. Delete permanently a program :


Before you delete permanently, make sure you select the correct recording to delete. Once the recording is deleted permanently, it **cannot be recovered**.

- Select a program to permanently delete from your list.
- Click **Delete Permanently**.




4. Confirm deletion:

- Press **Confirm** to delete permanently the recording.



5. A message will appear at the bottom of the screen to confirm that space has been successfully freed up in the upper right corner of the screen.



 **Tip :**

- **Keep an eye on available space:** You can see the free space in the upper right corner of the screen.
- **Permanently deleted recordings cannot be recovered.**

Need more recording hours? All you have to do is increase your number of recording hours by adding an additional block of hours to your plan.